


ITEM	PART	DESCRIPTION
1	120629	Knob-Housing
2	120638	Fan Guard 4.5"
3	120640	Fan
4	1266100	Fader Spring
5	126665	Lens 5x6
6	126689	3/8" Collar
7	127110	Tray
8	127113	Yoke Mount Stamping
9	127117	1271 Color Boom
10	127121	1271 Hood Right Hand
	127122	1271 Hood Left Hand
12	127130	Fader Control Rod Assembly
13	127131	Iris Control Rod Assembly
15	127132X	Moving Extrusion w/Rod
16	12061B	Reflector

ITEM	PART	DESCRIPTION
17	127116	Fader Assembly w/Linkage
18	127135	Iris Partition Assembly
19	127136	Lens Partition Assembly
20	127138X	Lamp Holder Assembly Comp.
21	127125X	Upper Lamp Insulator Asmb.
22	127126	Lower Lamp Insulator
23	127139	1271 Wiring Harness
24	127141	HV Lamp Lead
25	127142	Upper Lamp Lead
26	127143	Guide Rod
27	127144	Push Button Safety Switch
28	12719	12" Yoke Assembly
	229	Timer - DC
30	248	"ON" Button
31	249	"OFF" Button
	270	Yoke Backing Plate

# INTERIOR



ITEM	PART	DESCRIPTION
33	271	Indicator
34	287-4	4" Handle
35	35019	Iris
36	929	Igniter/Operation Unit
37	127533	Handle - 5"
38	120628	2 1/2" 5 Point Knob M-3/8
39	126659	Housing Fastener - 3 Parts
40	120628	2 1/2" 5 Point Knob M-3/8
41	940	Caster
42	120642	Gold Height Lever
43	13152X	Outer Base Pole
44	35101	Pole for Base
45	131555	Folding Base Leg
46	8561-S-12	Captive Screw
47	217	Leveling Jack (for 1315)
	127134	Assembly Partition Reflector

LENS OPTIONS	
<u>#127115 Short Lens Assembly</u>	
126666	Lens 6" x 20"
126613	Snoot Bead
<u>#127114 Medium Lens Assembly</u>	
317	Lens 8" x 26" WP
120669	Snoot Bead
<u>#127118 Long Lens Assembly</u>	
126755	Lens 11" x 39"
273	18" Handle
35041	Snoot Bead
81264-31-A	Spacer 5/8" D x 1 1/4" L